Porsche 4.0T 500 kW / 680 PS



The product described in the guidance was developed, manufactured and controlled considering the necessary safety reguirements.

The product must be installed properly to ensure a proper function and avoid danger for persons and things.

Please read this installationguide inclusive safety instructions carefully.

Scope of supply

Quantity	article
1x	Chiptuning Box
1x	Loom
1x	Bridge plug
1x	Fastening Kit



- 1. Open the hood.
- 2.Turn the ignition off!
- 3. Remove the ignition key!
- 4. Close and lock all doors!
- 5.Do not open any doors while installing the tuningkit!
- 6. Wait 5 minutes before beginning the installation









In order to avoid damages at electronic vehicle components, you have to be sure that you have done all necessary methods for **electostatic discharge** .

Install the electronic in an **heat-, waterproof** and **vibra-tionless** place. Do not make any changes at the tuning-kit!

Do not expand or shorten the loom.

Date: 02.10.2018 Side: 1 Version 2

Porsche 4.0T 500 kW / 680 PS





Installation by a specialist workshop (recommended)

We recommend that the installation of the power increase be carried out by a specialist workshop.

The position of the sensors is difficult to access.

We are happy to call you a service partner in your area.


Preparation:

Simply release the cover to release the sensors.

Date: 02.10.2018 Side: 2 Version 2

Porsche 4.0T 500 kW / 680 PS





Overview:

The chip tuning box will be connected to the following points:


- Boost-Plug 1 + 2
- Manifold-Plug 1+ 2
- Camshaft-Plug
- Power-Supply

Required tools:

- Ratchet with extension (13er, 17er)
- Side cutter

Porsche 4.0T 500 kW / 680 PS





1. Preparation

Before you can begin the installation, you must remove the engine cover.


To do this, loosen the screws on the left and right of the strut bar. Then the strut bar can be folded away to the right or left.

The engine cover is only attached with clips



Porsche 4.0T 500 kW / 680 PS





2. Manifold 1


Disconnect the plug from the inlet manifold sensor 1. Attach the manifold sensor plug to the new loom.

Connect the plug of the new loom to the manifold sensor1.



Porsche 4.0T 500 kW / 680 PS





3. Saugrohrdrucksensor 2


Disconnect the plug from the inlet manifold sensor 2. Attach the manifold sensor plug to the new loom.

Connect the plug of the new loom to the manifold sensor2.




Porsche 4.0T 500 kW / 680 PS





4. Cam-Shaft-Plug 1


The camshaft sensor is located at the rear of the engine below the water cooler



Disconnect the plug from the camshaft sensor.

Attach the camshaft sensor plug to the new loom

Connect the plug of the new loom the camshaft sensor






- The plug must be as show on the picture will be with the shallow edge on the side of the ridge.
- With some higher force, it is possible to push the plug with the round side on the ridge!!!

Porsche 4.0T 500 kW / 680 PS





5. Cam-Shaft-Plug 2

The camshaft sensor is located at the rear of the engine below the water cooler




Disconnect the plug from the camshaft sensor.

Attach the camshaft sensor plug to the new loom

Connect the plug of the new loom the camshaft sensor

Porsche 4.0T 500 kW / 680 PS





5. Camshaft-Plug

The camshaft sensor is located at the rear of the engine below the water cooler




Disconnect the plug from the camshaft sensor.

Attach the camshaft sensor plug to the new loom

Connect the plug of the new


Porsche 4.0T 500 kW / 680 PS





5. Power Supply

Remove the cover.




Connect the red cable of the new wiring harness to the positive pole of the battery.

Connect the black cable of the new harness to the negative (ground) of the car.

Porsche 4.0T 500 kW / 680 PS






6. Tuning box

Finally install the cable towards a suitable position

The plugs must be engage, so that a safe connection is ensured

Fix the cable with cable ties

Connect the tuningbox to the new loom



7. Blind plug

By using the jumper the vehicle is put in the original condition.

As soon as you connect the cable loom with the jumper plug the car is in original condition.

Porsche 4.0T 500 kW / 680 PS



FAQ

		l
Error Description:	How to fix this error:	
	Please check the plug-in connection of the affected sensor all sensors are plugged in properly.	s, make sure that
Engine doesn't start	Make sure that the 12V power supply is connected correct	ly, if available.
	Unplug the chiptuning box, plug the bridge connector, and whether the error persists.	then check
Engine "jerky"	Check all connections, have you plugged in a plug incorrect properly locked?	:ly or is it not
	Have you removed one of the plugs under current? (Open the doors, close and wait for 5 minutes)	the hood, close
Car goes immediately into limp mode	Please check the wiring harness.	
	Unplug the box, insert the bridge connector, and then checerror persists.	ck whether the
	Make sure you are on the correct plugs.	
Car without power increase	Please check the goods for possible damages and compare on the box with the one in the webshop.	the item number
	Only gasoline: Make sure you have fueled the right fuel wit (98 RoZ) or a higher quality.	th min Super Plus
Strong soot development in the	Only after consultation, change the chip tuning box down bing switch by 1 to 2 steps.	by the rotary cod-
engine	If you have a chiptuning box with app, set it to "ECO".	
Fueing has wisfing	Please unplug the chiptuning box and plug the bridge plug.	
Engine has misfire	Then try again to see if the error still occurs.	
Date: 02.10.2018	Side: 12	Version 2