


INSTRUCTION

JTD-STECKER

RIGHT POSITION



The JTD-Plug Clip (male plug) have to be on the same side as the angled plastik-part (female plug).

WRONG POSITION



- The JTD-Plug Clip (male plug) must not to be on the same side as the angled plastik-part (female plug).